

# Quoins Installation Guide



- Define and mark position.



- If you want the stones to border the corner of the house, there are 2 possible cuts.
  - 1) Cut the corner stones so that the chamfer remains visible, or



- 2) Cut the chamfer away.



- The butt joints and mitre joints must be glued and grouted with the DOMOSTYL®HYBRID adhesive.





- Stones can be installed in offset, row or interspersed.

